

PROFESSIONAL MEETING MICROPHONE

INSTRUCTION MANUAL

H-33/H-33B

This product is specially designed and made for various kinds of meeting, lectures, broadcasting, recording occasion, etc. It adopts high quality condenser cartridge to make sure that the microphone has high sensitivity and good frequency response. Please read the following instruction carefully before use the microphone

Specifications:

1. Capsule Type: Condenser
2. Polar Pattern: Cardioid
3. Frequency Response: 40Hz-16 KHz
4. Sensitivity: -45dB±2dB
5. Output Impedance: 200 Ohm - Unbalanced
6. Power Supply: DC9V/AC220V (option)

Operation Instruction

1. Insert the battery with the correct polarity and connect the audio cable
2. Adjust the volume of the amplifier to the minimum level.
3. Turn on the power switch of the amplifier and meeting microphone, and then adjust the volume of the amplifier slowly to desired level.
4. There has power on/off switch and music level knob on the microphone

Caution

1. The speaker will whistle if microphone is too near the speaker or the volume of the amplifier is too high, take care of keep certain distance and to limit the volume of the amplifier otherwise maybe cause to the amplifier or the speaker.
2. Take out the battery if the microphone will not be used for a long time, or the device maybe damaged by the spillage of the degenerative battery.